



- 1- Remove the rubber protections.**
1- Rimuovere le protezioni in gomma.



- 2- Remove the original screws.**
2- Rimuovere le viti originali.



A - 2 pcs



- 3- Fix the handguards (A) to the side mount brackets (LH)/ (RH) with the screws (D).**
3- Fissare i paramani (A) ai bracciali (LH)/(RH) tramite le viti (D).



- 4- Attach the handguards to the handlebar using the bushings (see tab.1), the screws (C) and the washers (I).**
4- Assemblare i paramani al manubrio attraverso le boccole (vedi tab.1), le viti (C) e le rondelle (I).



LH - 1 pcs



RH - 1 pcs



C - 2 pcs



D - 4 pcs



- 5- Fix the brackets with the bands (H).**
5- Fissare attraverso le fascette (H).



TAB. 1



E - 2 pcs



F - 1 pcs



G - 1 pcs



H - 2 pcs



I - 2 pcs

BARCODE LABEL
100X50 MM

MOUNTING KIT INCLUDED
KIT DI MONTAGGIO INCLUSO

